

1. Flooring material must be acclimated according to the manufacturer's recommendations and/or requirements.
2. Moisture testing (either CaCl or RH) and pH testing should be performed before installation in accordance with current professional standards.

pH limit – 11
Moisture limit - 18 lbs CaCl – (ASTM F 1869)
Relative humidity – up to 99.0%

- 3a. All sub-floor contaminants, construction material, crayons, paints and residual adhesives **MUST** be removed by mechanical means. **DONOT** use chemical adhesive remover. (Use of chemical agents (natural or synthetic) MAY reduce the adhesion properties and will void any and all warranties on the EnviroSTIX® product.)
- 3b. To insure proper adhesion a bond test is required on 1 square foot of installation space per 1,000 square feet of substrate.
4. All surfaces must be dust free. The use of EnviroSTIX® Primer/Sealer is required to ensure all surfaces are free of foreign matter. **NOTE:** Failure to use a primer will void all aspects of the EnviroSTIX® adhesive bond warranty.
5. To ensure proper placement, make cuts and layouts with paper backing **ON** prior to removal of EnviroSTIX® backing.
6. When you are ready to place carpet tiles on floor, keep in mind the EnviroSTIX® adhesive is a more permanent installation and the adhesive adheres immediately. To ensure easier installation, do not remove the paper liner completely. Instead, start by peeling 6 to 9 inches from the corner of the tile.

Next, take the tile with exposed corner and place it in the desired position on floor.

Once in desired location, press the exposed corner to floor.

Raise up the tile to remove the remaining release liner exposing the balance of the adhesive.

Align edges as needed and press the tile firmly into place.

HINT: If some shifting of the material (ex. toe kicks or sliding under door jams, etc...) is required or you are having trouble placing material, the sub-floor can be lightly misted with a regular spray bottle and water or use a damp sponge to moisten the exposed adhesive on the tile before exposed adhesive touches floor/surface. This will give an installer a 10-30 second window (based on room temperature, relative humidity and coverage area this time will vary) to shift material into place.

1. After you have installed the tile, use a **100 lb. (or greater) roller** to roll material in both directions. Floor is now ready for immediate use. (foot traffic, furniture, rolling carts, etc...)
2. Maintain the floor per manufacturer recommendations.* Cleaning by using a mild detergent or any non-solvent cleaner is allowed
3. If this is the 1st time you've installed flooring using the EnviroSTIX® Adhesive System, it is strongly recommended you call Base King, LLC® at 1-888-428-3106 to speak with technical support regarding specific installations tips, hints and recommendations.

IMPORTANT NOTE: If your project is a renovation of an existing space, EnviroSTIX® has specific demolition and floor prep information. You must contact Base King, LLC® at 1-888-428-3106 for recommendations and suggestions for handling old adhesives and other aspects unique to renovation projects.

*Check carpet tile manufacturer's maintenance and cleaning recommendations

1. El material del piso tiene que estar aclimatado en acuerdo con las recomendaciones o requisitos de la fábrica.
2. La prueba de humedad (El CaCl o RH) y la prueba de pH, deben de estar hechas antes de ser instalados de acuerdo con las garantías profesionales. pH Límite-11 Límite de humedad-181bs CaCl-(ASTM F 1869) Humedad relative-hasta 99.0%
- 3a. Todos los sub-suelos contaminantes, material de construcción, crayolas, pinturas y residuos adhesivos, TIENEN QUE ser removidos mecánicamente. NO USE químicos adhesivos para removerlos. (El uso de químicos (Naturales o Sintéticos) PUEDE reducir las propiedades de la pegadura y serán inválidas todas las garantías del producto de EnviroSTIX®).
- 3b. Para asegurar una adhesión adecuada una prueba de adherencia se requiere en un pie cuadrado de espacio de instalación por cada 1.000 pies cuadrados de sustrato.
4. Todas las superficies, deberán de estar libres de polvo. El uso de latex o Primer epoxy, es requisito para asegurar que todas las superficies están libres de otros residuos. NOTA: Si no se usa el Primer, se anulará toda la garantía de la pegadura EnviroSTIX®. Algunos primers son Ardex P-51, XL Encore Prelude o equivalente.
5. Para asegurar que es el lugar correcto, haga un patrón. Corte el EnviroSTIX® con el papel que tiene anexo al mismo.
6. Cuando usted esté listo para poner el tapiz de alfombra al piso, no se olvide que la pegadura EnviroSTIX® la instalación es más permanente y la pegadura se adhiere inmediatamente. Para asegurar más fácil la instalación, no quite el papel de atrás completamente, empiece a despegar por una esquina de 6" a 9"(15cm a 22cm). -Siguiente paso, tome el tapiz de alfombra de una esquina y póngala en el lugar deseado en el piso, una vez deseado el lugar, presiónelo firmemente hasta que quite el resto del papel de atrás con la pegadura. -Aiiine todas las esquinas dando presión firmemente en su lugar. SUGERENCIA: Si el material se mueve un poco fuera del lugar o está teniendo problemas poniendo el material, moje un poco el sub-suelo puede usar un rociador con agua o use una esponja mojada en la pegadura del tapiz de alfombra antes de ponerlo en el piso. Esto le dará de 10 a 30 segundos para acomodarlo a la perfección (ésto también dependerá de la temperatura y la humedad del lugar).
7. Después que está instalado el piso, use un rodillo de 100 libras o más en ambas direcciones, el piso estará listo para usarse inmediatamente.
8. Limpie y mantenga el tapiz de alfombra de acuerdo a las instrucciones recomendadas por la fábrica.*
9. Si ésta es la primera vez que ha instalado piso, usando el sistema adhesivo de EnviroSTIX®, es fuertemente recomendado, llame a: Base King, LLC al: 1-888-428-3106 para hablar con un técnico especializado en instalación. Español disponible.

NOTA IMPORTANTE: Si su proyecto es una renovación, de un lugar existente, EnviroSTIX® tiene información específica para hacer demolición y preparar el piso. Favor de comunicarse a: Base King, LLC al: 1-888-428-3106, para recomendaciones y sugerencias de cómo quitar el pegamento viejo u otros aspectos únicos a proyectos de renovación. *Revise las recomendaciones de mantenimiento y limpieza de la fábrica.