



INSTALLATION RECOMMENDATIONS

1. Flooring material must be acclimated to manufacturers recommended temperature.
2. Moisture, relative humidity, pH and bond tests should be performed before installation
 - pH limit-11
 - Moisture limit-18 (ASTM F 1869)
 - Relative humidity-up to 100%
3. All subfloor contaminants, construction material, crayons, paints and residual adhesives **MUST** be removed by mechanical means. **DO NOT** use chemical adhesive remover. (Use of chemical adhesive remover will reduce the adhesion properties and will void any and all warranties on this product.)
4. All surfaces must be dust free and use of a Latex or Epoxy Primer is recommended to ensure all surfaces are free of foreign matter. **NOTE:** Use of a primer is necessary to maintain adhesive bond warranty.
5. To ensure proper placement/pattern, lay material in place with paper backing **ON** prior to removal of EnviroSTIX™ backing.

6. Once material is in place, begin to remove the paper backing. The material with exposed adhesive will stick immediately to the surface. HINT: Gradually remove paper liner in short sections/increments until proper alignment is achieved. If some shifting of the material is required the subfloor can be slightly misted with a regular spray bottle and water (before exposed adhesive touches floor/surface). This will give the installer a 10-15 second window (based on room temperature, relative humidity and coverage area this time will vary) to jog material into place. Please note: too much water can reduce adhesion and mist amounts should be tested in similar conditions prior to installation if possible.
7. After installation, using a 100lb. roller (recommended), roll over material both horizontally and vertically to ensure a solid contact has been made with the subfloor.
8. Weld material per project specifications. Heat welding can be done *immediately*. Foot traffic and rolling loads will not affect bonding of material to subfloor.